



NOTES:

PLANTING SOIL:

SUBDIVISIONS: CONFIRM NATIVE TOPSOIL CONDITIONS PRIOR TO PLANTING. REFER TO TOPSOIL NOTES, TN-1.
SITE PLANS: REFER TO STANDARD LANDSCAPE NOTES, LN-1.

ENSURE TOPSOIL IS WELL AERATED AND PULVERIZED, FREE OF DEBRIS AND CONTAMINENTS. LIGHTLY COMPACT IN PLANTING BED AND WATER WELL TO ELIMINATE AIR POCKETS AND PREVENT SETTLEMENT.

ROOT CONDITION:

PLASTIC POT: REMOVE ENTIRELY. ENSURE ROOT BALL IS FIRM AND INTEGRAL WITH THE PLANT.
FIBRE POT: REMOVE TOP 1/3 OF POT. CUT REMAINING SIDES AND LOOSEN POT FROM SOIL.
BURLAP: REMOVE ALL ROPES AND BURLAP FROM TOP 1/2 OF ROOT BALL.

MULCH: TO BE SHREDDED CONIFEROUS BARK MULCH: PROVIDE SAMPLES PRIOR TO PLANTING.

PLANTING PIT: FOR INDIVIDUAL SHRUBS DIG PLANTING PITS 300mm WIDER ON ALL SIDES OF ROOT BALL. FOR PLANTING BEDS PROVIDE A CONTINUOUS EXCAVATED PLANTING PIT.